

RangerWare

By  POLARIS®



Sliding Rear Window Installation

THIS IS AN EASY UPGRADE BUT WILL GO FASTER AND SMOOTHER WITH AN EXTRA PAIR OF HANDS!

Note: This sliding rear window may be installed with the rear panel installed on the vehicle; however, not all fasteners (Phillips screws) will be readily accessible due to the roll cage and headrests. A socket and short Phillips bit or flexible screw driver may be required.

1. Open the locking strip on the rubber window seal and remove the rear window and seal from the opening.
2. Remove the aluminum trim ring from inside of the new window.
3. From the outside, position the new window in the opening. Make sure the drain slots are on the bottom and the window is centered in the opening.
4. From the inside, align the trim ring over the groove in the window frame. Press the trim ring into the headliner and secure each end using the Phillips screws provided. **Caution: Do not strip out the screws by over tightening.** Install the remaining screws working from each end towards the center.

Ranger *Ware*

By



POLARIS®



