

REAR TINE TILLER

SPECIFICATIONS:

Honda GC190 4-Stroke Engine
Self Propelled Drive w/Forward and Reverse
Forward or Counter Rotating Tines
18" Tilling Width
Adjustable Depth Bar



PROCEDURES:

- Customer will be instructed on depth gauge and locking mechanism.
- Instruct customer of shear pin/bolts in case he hits something hard. Grade 5 only.
- On/Off switch located on handle controls.
- Ramps will provided at no charge, for loading and unloading.
- Unit is not recommended for lawn repair.
- Clean air filter and check oil level every full tank.
- SHUTDOWN: Allow engine to idle down approximately 5 minutes to reduce engine heat from burning protective coating of oil in cylinder.
- Clutch must be disengaged before putting unit into gear.
- Tines will rotate when unit is in gear.
- If customer calls with tines not having proper power, tell customer to check clutch cable tension.
- Customer will be charged for any clean up or damage due to neglect.

Trouble Shooting:

- Check Fuel level.
- Change spark plug.
- Make sure belt is tight or not broken.
- Check that safety handle cable is not broken.
- Be sure shear bolts are in place. Grade 5 bolts only.
- Check/Clean air filter