

# RAMMER-JUMPING JACK

## SPECIFICATIONS:

4 HP Engine  
13" X 13" Shoe Size  
3140 lbs. BPM  
23" of Fill can be compacted.  
Weight: 150 lbs.  
3.3 qt. Fuel Tank



## PROCEDURE:

- This unit will meet state compaction codes when proper fill and compaction procedures observed.
- Check hydraulic oil level and clean air filter every 4 hours of use.
- Shutdown: Allow engine to idle down approximately 5 minutes to reduce engine heat from burning protective coating of oil in cylinder.
- Customer will be charged for any cleanup or damage due to neglect.
- Turn fuel control valve to the "off" position .
- Green tag with rental number

## TROUBLE SHOOTING

- Unit lacks power:
  1. Check fuel level.
  2. Check condition of air filter and spark plug.
  3. Check fuel filter.
  4. Make sure gas tank is vented. Try again.