

# NOW AVAILABLE!

## PG PARTS™ FOR CARRIER® COMFORTPRO™ UNITS



### ASK YOUR LOCAL THERMO KING DEALER FOR THE NEW PG PARTS™ CATALOG AND SEE THE FULL LINE OF PARTS FOR CARRIER® UNITS

See back for listing of ComfortPro™ Parts

 **THERMO KING**

54688-15-PL

Your Thermo King dealer can help service and support your Comfort Pro equipment by offering the following parts:

Description	PG Part #	Carrier Part #	PC5000	PC6000
Alternator, 40 Amp DC	P-96-111-02K	96-111-02K	X	
Alternator, 60 Amp DC	P-96-101-21K	96-101-21K		X
Belt, Alternator/Fan/Water Pump	P-96-969-03K	96-969-03K	X	X
Belt, Generator	P-40-304-01K	40-304-01K	X	X
Capacitor, 25 MFD	P-40-203-20K	40-203-20K	X	X
Compressor, Base R134a	P-55-810-01KC	55-810-01K		X
Compressor, Base R22	P-55-376-01KC	55-376-01K	X	
Compressor, shockmount kit	P-30-781-05KPG	30-781-05K	X	X
Drier	P-55-831-01K	55-831-01K		X
Fan, Axial kit	P-55-352-01K	55-352-01K	X	
Filter Fuel, In-Line case 12	P-30-186-02K	30-186-02K	X	X
Filter Fuel, In-Line - Single	P-30-186-02KS	30-186-02K	X	X
Filter, Fuel case 12	P-30-814-11K	30-814-11K	X	
Filter, Fuel - Single	P-30-814-11KS	30-814-11K	X	
Filter, Oil case 12	P-96-101-33K	96-101-33K		X
Filter, Oil - Single	P-96-101-33KS	96-101-33K		X
Filter, Oil case 12	P-96-952-02K	96-952-02K	X	
Filter, Oil - Single	P-96-952-02KS	96-952-02K	X	
Filter, Air - Single	P-30-60049-20	30-724-11K	X	X
Filter, Fuel case 12	P-96-101-24K	96-101-24K		X
Filter, Fuel - Single	P-96-101-24KS	96-101-24K		X
Fuel, Solenoid c/w connector	P-30-122-05K	30-122-05K	X	
Gasket, Fuel pump	P-30-378-02K	30-378-02K	X	
Gasket, Injector	P-25-34216-00	96-943-01K	X	X
Gasket, Thermostat	P-25-36676-00	30-229-01K	X	X
Gasket, Water pump	P-25-34333-00	30-124-01K	X	X
Glow Plug	P-25-15330-00	96-937-00K	X	X
Injector, c/w gasket and heat seal	P-96-943-00K	96-943-00K	X	X
Pulley, Fan	P-96-969-04K	96-969-04K		X
Pump, Fuel suction	P-30-377-01K	30-377-01K	X	
Pump, Water	P-25-34330-00SVB	30-123-01K	X	X
Pump, Water (new style)	P-96-101-30k	96-101-30K		X
Seal, Heat injector	P-25-39147-00	96-943-02K	X	X
Sensor, Coolant	P-30-266-01K	30-266-01K	X	X
Sensor , Oil pressure	P-96-949-00K	96-949-00K		X
Solenoid, Fuel shutoff	P-96-153-01K	96-153-01K		X
Solenoid, Starter	P-25-34893-00	30-125-02K	X	
Starter, Engine	P-25-34885-00	30-125-01K	X	
Starter, Engine c/w solenoid	P-96-101-22K	96-101-22K		X
Switch, Binary	P-55-851-01K	55-851-01K		X
Thermostat, Engine	P-25-34309-01	30-228-01K	X	X
TXV, Kit	P-55-817-01K	55-817-01k		X