

## Replacement Keys and Caps

### Replacement Keys and Key Caps

When a customer loses a key, Yamaha makes it easy for you to get them a new one.

**If they have lost all their keys, just locate the key number off the main switch barrel.**

#### 700 Series Keys

Key	Part Number	Key	Part Number	Key	Part Number
721	90890-56004-00	732	90890-56008-00	750	90890-56012-00
727	90890-56005-00	733	90890-56009-00	751	90890-56013-00
730	90890-56006-00	741	90890-56010-00	752	90890-56014-00
731	90890-56007-00	747	90890-56011-00	753	90890-56015-00

#### 300 Series Keys

Key	Part Number	Key	Part Number	Key	Part Number
371	90890-55868-00	378	90890-55875-00	385	90890-55882-00
372	90890-55869-00	379	90890-55876-00	386	90890-55883-00
373	90890-55870-00	380	90890-55877-00	387	90890-55884-00
374	90890-55871-00	381	90890-55878-00	388	90890-55885-00
375	90890-55872-00	382	90890-55879-00	389	90890-55886-00
376	90890-55873-00	383	90890-55880-00	390	90890-55887-00
377	90890-55874-00	384	90890-55881-00		

#### 800 Series Keys

Key	Part Number	Key	Part Number	Key	Part Number
821	90890-56016-00	832	90890-56020-00	850	90890-56024-00
827	90890-56017-00	833	90890-56021-00	851	90890-56025-00
830	90890-56018-00	841	90890-56022-00	852	90890-56026-00
831	90890-56019-00	847	90890-56023-00	853	90890-56027-00

#### 400 Series Keys

Key	Part Number	Key	Part Number	Key	Part Number
451	90890-55820-00	458	90890-55827-00	465	90890-55834-00
452	90890-55821-00	459	90890-55828-00	466	90890-55835-00
453	90890-55822-00	460	90890-55829-00	467	90890-55836-00
454	90890-55823-00	461	90890-55830-00	468	90890-55837-00
455	90890-55824-00	462	90890-55831-00	469	90890-55838-00
456	90890-55825-00	463	90890-55832-00	470	90890-55839-00
457	90890-55826-00	464	90890-55833-00		

#### Command Link®/Command Link Plus® Series Keys

Key	Part Number	Key	Part Number	Key	Part Number
457	6X6-82511-09-A1	832	6X6-82511-09-A5	853	6X6-82511-09-A9
462	6X6-82511-09-A2	833	6X6-82511-09-A6		
463	6X6-82511-09-A3	847	6X6-82511-09-A7		
827	6X6-82511-09-A4	852	6X6-82511-09-A8		

#### Yamaha Key Covers


Key covers are weather resistant and branded with the Yamaha name. Replacement keys come without a cover.

300 / 700 Series Key Cover: 703-82577-00-00

14mm Switch Cover for 300 / 700 Series Keys: 6K1-82532-00-00

400 / 800 Series Key Cover: 676-82577-01-00

15mm Switch Cover for 300 / 700 Series Keys: 703-82532-00-00



300/700 Series



400/800 Series

General Information

Rigging Estimate Guide (Diagrams)

Rigging Components

Electrical Components

Engine Accessories

Propellers

Maintenance Items

Oils & Lubes

Detailing & Trailer Supplies

Accessories & Apparel

Generators & Accessories