
KUKJE A2300T8-ETX_4 Branson Engine

Parts Catalogue



BRANSON TRACTOR

CONTENTS

GROUP NO	GROUP NAME	PAGE
00205_01	CYLINDER BLOCK)	3
00205_02	GEAR CASE	5
00205_03	FLYWHEEL HOUSING & OIL PAN	7
00205_04	CYLINDER HEAD & HEAD COVER	9
00205_05	INTAKE MANIFOLD	12
00205_06	COMPRESSOR BRACKET	14
00205_07	EXHAUST MANIFOLD & SILENCER	16
00205_08	CAM SHAFT & DRIVING GEAR	18
00205_09	CRANK SHAFT & PISTON	20
00205_10	BALANCER	22
00205_11	LUB. OIL SYSTEM	24
00205_12	COOLING SYSTEM	26
00205_13	FUEL INJECTION PUMP	28
00205_14	FUEL INJECTION SYSTEM	30
00205_15	FUEL SYSTEM	32
00205_16	STARTING MOTOR	34
00205_17	GENERATOR & ELECTRIC DEVICE	36
00205_18	DPF MOUNTING	38
00205_19	DPF OPTION	40
00205_20	DATAPLATE	42

FIG 00205_01 A2300T8-ETX_4	CYLINDER BLOCK)	Year/Month 2020/02




FIG 00205_01 A2300T8-ETX_4	CYLINDER BLOCK)	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HRA0103100A9	BLOCK ASS'Y, CYLINDER	1	
2	HRA0103101A0	BLOCK, CYLINDER	1	
3	HRA0100102B3	CAP,MAIN BEARING	1	
4	HRA0100103B3	CAP,MAIN BEARING	4	
5	HRA0100104A4	SCREW,HEXFLANGEHEADCAP	10	
6	22351-030010	PIN, SPRING (3-01)	1	
7	27241-300000	PLUG (D30)	8	
8	HRA0100108A4	PLUG,EXPANSION	3	
9	27231-500000	PLUG,EXPANSION	1	
10	23871-020000	Plug, Pipe	1	
12	HM23030000A4	PLUG	1	
13	HRU0100105A3	BUSH, CAM SHAFT	1	
14	HRA0100200A9	BEARING,MAIN- >HRA0100201A3 HRA0100202A3	5	
14-1)	HRA0100201A3	BEARING,MAIN (UPPER)	5	
14-2)	HRA0100202A3	BEARING,MAIN (LOWER)	5	
17	HRA0100300A9	BEARING,CRANKSHAFT THRUST	2	
17-1)	HRA0100301A3	THRUST BEARING,CRANKSHAFT (UPPER)	2	
17-2)	HRA0100302A3	THRUST BEARING,CRANKSHAFT (LOWER)	2	
20	HRU0100400A2	GASKET,CYLINDER HEAD (A2300)	1	
21	HRA0100500A4	SCREW,HEXFLANGEHEADCAP	14	
23	23871-010000	PLUG	1	
24	HRT0300500A4	PLUG,EXPANSION	1	
27	HRA0100700A4	SCREW,HEXFLANGEHEADCAP	4	
28	HRA0100800A4	PIN,OIL	1	

FIG 00205_02 A2300T8-ETX_4	GEAR CASE	Year/Month 2020/02




FIG 00205_02 A2300T8-ETX_4	GEAR CASE	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HRA020010DD2	PLATE, GEAR COVER	1	
2	HM02380000A4	STUD	3	
3	HK02380000A4	STUD	1	
4	EA00000527C	COVER,FRONT	1	
5	EA00000413E	COVER,FRONT	1	
6	HRC0200402B4	OIL SEAL (G)	1	
7	HC03470000B4	CAP,FILTER	1	
8	24311-000320	O-RING, DYNAMIC (Φ32)	1	
9	HC01230000C4	COVER,ACCESSORYDRIVE	2	
10	HA02110000B4	GASKET,ACCDRIVECOVER	2	
11	HRA0201100A4	PIN,GUIDE	2	
12	26216-080162	STUD	4	
14	23414-080000	WASHER, PLAIN (Φ8)	1	
16	24311-000160	O-RING, DYNAMIC (Φ16)	2	
18	26106-080122	Bolt, Hexa (8-12)	4	
19	26116-080162	SCREW,HEXAGONHEADCAP	3	
20	26106-080222	SCREW, HEX FLANGE HEAD CAP	1	
21	26106-080602	SCREW,HEXFLANGEHEADCAP	3	
22	26106-080902	SCREW,HEXFLANGEHEADCAP	2	
23	26106-080852	SCREW,HEXFLANGEHEADCAP	7	
24	26106-080502	SCREW,HEXFLANGEHEADCAP	1	
25	26367-080002	HEX FLANGE NUT (Φ8)	7	
31	24341-000500	O-RING, FIX (Φ50)	1	

FIG 00205_03 A2300T8-ETX_4	FLYWHEEL HOUSING & OIL PAN	Year/Month 2020/02




FIG 00205_03 A2300T8-ETX_4	FLYWHEEL HOUSING & OIL PAN	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	22312-080160	PIN, DOWEL (8-16)	2	
2	HRA0300200B1	MOUNTING FLANGE	1	
3	26116-100202	HEX FLANGE BOLT(M10X1.5X20)	8	
4	HRA0300400C0	ADAPTER,OIL PAN	1	
5	23490-140002	Plug, Drain	1	
6	24311-000160	O-RING, DYNAMIC (Φ16)	1	
7	HRA0300700A1	COVER, LOWER	1	
8	HRA0300800A4	PIN,GUIDE	1	
9	26106-080122	Bolt, Hexa (8-12)	8	
10	26106-080502	SCREW,HEXFLANGEHEADCAP	8	
11	26106-081202	SCREW,HEXFLANGEHEADCAP	16	
12	26116-081202	SCREW,HEXAGONHEADCAP	2	
13	22217-080000	WASHER, SPRING (Φ 08)	2	
14	22312-080160	PIN, DOWEL (8-16)	2	
15	HRC0300800A9	OIL SEAL HOUSE Ass'y	1	
16	HRA0301401B2	OILSEAL CASE	1	
17	HRC0300802A4	OIL SEAL (F)	1	
18	26106-080302	HEX BOLT, FLANGE	9	
19	HF01470000A4	MAGNET	1	

FIG 00205_04 A2300T8-ETX_4	CYLINDER HEAD & HEAD COVER	Year/Month 2020/02




FIG 00205_04 A2300T8-ETX_4	CYLINDER HEAD & HEAD COVER	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00000635A	HEAD, CYLINDER	1	
2	EA00000624A	HEAD, CYLINDER	1	
3	HRA0400102B4	GUIDE,VALVESTEM	4	
4	HRA0400103B4	GUIDE,VALVESTEM	4	
5	HRA0400104B4	SEAT,ENGINEINTAKEVALVE	4	
6	HRA0400105B4	SEAT,ENGINE EXHAUST VALVE	4	
7	27241-400000	PLUG (D40)	2	
8	27241-220000	PLUG,EXPANSION	4	
9	27241-220000	PLUG,EXPANSION	4	
10	HRA0400200A4	VALVE,INTAKE	4	
11	HRA0400300A4	VALVE,EXHAUST	4	
12	22312-040100	PIN, DOWEL (4-10)	2	
13	HA03070000A4	SEAL,VALVESTEM	8	
15	HRA0400700A4	SPRING,VALVE	8	
16	HRA0400800A4	RETAINER,VALVESPRING	8	
17	HRA0400900A4	COTTER,VALVE	16	
18	HK03680000B4	CAP,VALVE	8	
19	HRA0401100B2	LEVER,ROCKER	1	
20	HRA0401200A4	SUPPORT,ROCKERLEVER	1	
21	HRA0401300A4	SUPPORT,ROCKERLEVER	3	
22	HRA0401400A4	SPRING,COMPRESSION	3	
23	HRA0401500A2	SHAFT,ROCKERLEVER	1	
24	HRA0401600A4	LEVER,ROCKER	8	
25	AF02110000E4	SCREW,RKRLEVERADJUSTING	8	
26	HH05280000A4	NUT,VALVEADJUSTING	8	
27	26921-080102	SCREW,SLOTTEDSET	1	
28	22242-000190	SNAP RING, SHAFT (Φ 19)	2	
29	HRA0401800A4	STUD	4	
30	22117-120000	WASHER, PLAIN (Φ 12)	4	
31	HRA0402300B0	COVER,VALVE	1	
32	HRA0402400B3	GASKET,VALVECOVER	1	
33	HA03520000B4	NUT,HEXAGONCAP	4	
34	24311-000140	O-RING, DYNAMIC (Φ14)	4	
35	26587-040102	SCREW,FILLISTERHEADCAP	4	
36	HRA0403600A4	COVER,BREATHER	1	
37	HRA0403700A4	Valve, Pressure Relief	1	
38	HRA0403800A4	GASKET,BREATHER	1	
39	HRA0403900A4	PLATE,BREATHERADJUSTING	1	
40	HRA0404000A4	TUBE,BREATHER	1	
41	HLT0501000A4	HOSE,PLAIN	1	
42	23080-021000	CLAMP,VBAND	1	
43	HC03470000B4	CAP,FILTER	1	
44	24311-000320	O-RING, DYNAMIC (Φ32)	1	
45	HK03530000A4	BRACKET,LIFTING	1	
46	26106-080162	SCREW,HEXFLANGEHEADCAP	2	

FIG 00205_04 A2300T8-ETX_4	CYLINDER HEAD & HEAD COVER	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
47	EA00000083A	PRE-CHAMBER	4	
49	HRA0404900A4	SEAL,INJECTOR	4	
50	HRA0405000A4	SPACER, FUEL INJECTOR	4	
51	HA03180000B4	NUT,REGULARHEXAGON	4	
53	23871-010000	PLUG	1	
56	HC03720000B4	BAFFLE	2	
57	24341-000160	O-RING, FIX (Φ16)	1	

FIG 00205_05 A2300T8-ETX_4	INTAKE MANIFOLD	Year/Month 2020/02




FIG 00205_05 A2300T8-ETX_4	INTAKE MANIFOLD	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003502A	INTAKE MANIFOLD	1	
2	HRA0500200A3	GASKET,INTAKE MANIFOLD	1	
3	26106-080302	HEX BOLT, FLANGE	4	
4	26216-080352	BOLT, STUD 8 X 35	1	
5	26367-080002	HEX FLANGE NUT (Φ8)	5	
6	26213-080222	STUD BOLT	4	
7	EA00003585A	GASKET	1	
8	EA00003513A	FLANGE	1	
9	23000-048000	CLAMP,HOSE	2	
10	EA00003506A	INTAKE HOSE	1	
11	23871-030000	PLUG, PIPE	1	

FIG 00205_06 A2300T8-ETX_4	COMPRESSOR BRACKET	Year/Month 2020/02




FIG 00205_06 A2300T8-ETX_4	COMPRESSOR BRACKET	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	TA00025553A	BRACKET COMPRESSOR	0	
2	26106-100552	BOLT	0	
3	26367-100002	NUT,HEXAGONFLANGE	0	
4	26106-100252	SCREW,HEXFLANGEHEADCAP	0	

FIG 00205_07 A2300T8-ETX_4	EXHAUST MANIFOLD & SILENCER	Year/Month 2020/02




FIG 00205_07 A2300T8-ETX_4	EXHAUST MANIFOLD & SILENCER	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003150A	DATA PLATE ASSY	1	
2	HRA0600200A3	GASKET,EXHAUSTMANIFOLD	2	
3	26367-080002	HEX FLANGE NUT (Φ8)	12	
4	26106-080652	SCREW,HEXFLANGEHEADCAP	2	
5	26106-080952	FLANGEBOLT	4	
6	26216-080652	BOLT	2	
7	26213-080222	STUD BOLT	4	
8	HL0706000EB4	GASKET,TURBOCHARGER	1	
15	26216-080252	STUDBOLT	4	
16	EA00003708A	TURBOCHARGER	1	
17	23871-020000	Plug, Pipe	1	
18	HP0524000EA4	GASKET (T/OUT)	1	

FIG 00205_08 A2300T8-ETX_4	CAM SHAFT & DRIVING GEAR	Year/Month 2020/02




FIG 00205_08 A2300T8-ETX_4	CAM SHAFT & DRIVING GEAR	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HH08060000B4	TAPPET,VALVE	8	
2	HRA0700200B4	ROD,PUSH	8	
3	HRA0700300B9	CAM SHAFT ASSY	1	
4	HRA0700302A3	GEAR,CAMSHAFT	1	
5	22512-070140	KEY, SLIDING (07-14)	1	
6	HRA0700304A4	Bearing, Camshaft Thrust	1	
7	26106-080162	SCREW,HEXFLANGEHEADCAP	2	
8	EA00000848B	SHAFT, IDLER	1	
9	HRA0700600A3	GEAR,IDLER	1	
10	HH08120000A4	BUSH	1	
11	HRU0700700A4	BOLT,IDLESHAFT	2	
12	HRA070080DB3	GEAR,FUELPUMP	1	
15	22217-120000	WASHER, SPRING (Φ 12)	1	
16	26716-120002	BOLT,CYLINDER HEAD(B)	1	
17	HK02350000A4	GASKET,ACCDRIVECOVER	1	
18	HK02340000B3	HOUSING, POWER TAKEOFF	1	
19	HRA4000300A3	HYD.PUMP GEAR	1	
20	24101-060064	Bearing, Ball (#6006)	2	

FIG 00205_09 A2300T8-ETX_4	CRANK SHAFT & PISTON	Year/Month 2020/02




FIG 00205_09 A2300T8-ETX_4	CRANK SHAFT & PISTON	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HRA080010KD9	CRANKSHAFT	1	
2	HRA0800101D0	CRANKSHAFT	1	
3	22312-080160	PIN, DOWEL (8-16)	1	
4	24190-080002	Ball, Steel	1	
5	HRA0800200A3	GEAR,CRANK SHAFT	1	
7	HRA0800400A3	GEAR,BALANCERDRIVEN	1	
8	22512-070140	KEY, SLIDING (07-14)	2	
11	HRU0020100B2	PULLEY,CRANKSHAFT	1	
13	HRA0800800A4	WASHER,PLAIN	1	
14	HH09090000A4	SCREW,HEXFLANGEHEADCAP	1	
15	HRC0801000A4	SCREW,HEXAGONHEADCAP	6	
16	HRA084000DB9	FLYWHEEL ASS'Y(IND-4CYL)	1	
17	HRA084001DA1	FLYWHEEL(IND-4CYL)	1	
19	HA07070000A2	RING GEAR,FLYWHEEL	1	
21	HRA0801300A9	PISTON ASS'Y	4	
22	HRA0801301B1	PISTON,ENGINE	4	
23	HRA0801302B9	RINGSET,PISTON	4	
24	HRA0801303A4	RING,1STCOMPRESSIONPISTON	4	
25	HRA0801304B4	RING,2NDCOMPRESSIONPISTON	4	
26	HRA0801305B4	RING,OILPISTON	4	
27	HK27150000A4	PIN,PISTON	4	
28	HA08070000A4	RING,RETAINING	8	
29	HRA0801600A9	ROD,ENGINECONNECTING	4	
30	HRA0801601B2	ROD,ENGINE CONNECTING	4	
33	HRA0801603A4	BUSHING	4	
34	HRA0801602A4	SCREW,HEXAGONHEADCAP	8	
35	HRA0801700A3	BEARING,CONNECTINGROD	8	
36	HRC7001500A3	V PULLEY	0	
37	26013-080302	HEX BOLT W/WASHER	0	
38	24104-063024	BALL BEARING (#6302UU)	1	

FIG 00205_10 A2300T8-ETX_4	BALANCER	Year/Month 2020/02




FIG 00205_10 A2300T8-ETX_4	BALANCER	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HRA1000100A1	BALANCER	1	
2	HRA1000101A9	BALANCER CASE ASS'Y	1	
3	HRA1000109A0	CASE,BALANCER	1	
4	HRA1000102A3	BUSH,BALANCERSHAFT	4	
5	HRA1000200A9	SHAFTASS'Y(A),BALANCER	1	
6	HRA1000201A3	SHAFT(A),BALANCER	1	
7	HRA1000202A4	BEARING,THRUST	1	
8	HRA100203A3	GEAR B, BALANCER	2	
9	22312-060080	PIN, DOWEL (6-08)	1	
10	HRA1000300A9	SHAFTASS'Y(B),BALANCER	1	
11	HRA1000301A3	SHAFT(B),BALANCER	1	
12	HRA1000202A4	BEARING,THRUST	1	
14	22312-060080	PIN, DOWEL (6-08)	1	
15	HRA1000204A3	GEAR(A),BALANCER	1	
16	22312-060080	PIN, DOWEL (6-08)	1	
17	HRA1000500A4	NUT,BALANCERGEAR(A)	1	
18	24190-080002	Ball, Steel	2	
19	26106-080162	SCREW,HEXFLANGEHEADCAP	4	
20	24311-000140	O-RING, DYNAMIC (Φ14)	1	
21	26106-080652	SCREW,HEXFLANGEHEADCAP	4	
22	26106-080752	SCREW,HEXFLANGEHEADCAP	2	
23	HRA1000700A4	PIN,GUIDE	2	

FIG 00205_11 A2300T8-ETX_4	LUB. OIL SYSTEM	Year/Month 2020/02





FIG 00205_11 A2300T8-ETX_4	LUB. OIL SYSTEM	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HRA1100109A9	PUMP, LUBRICATING OIL	1	
2	HRA1100100A2	PUMP,LUBRICATINGOIL	1	
13	HRA1100112A3	GEAR,LUBRICATINGOILPUMP	1	
14	HRA1100600A4	GASKET,LUBOILPUMP	1	
15	26450-060252	SCREW,SOCKETHEADCAP	4	
16	HRD1100700A4	GASKET,OILPAN	1	
17	HRA1100800A2	PIPEASSY,OILINTAKE	1	
18	26106-080352	SCREW,HEXFLANGEHEADCAP	2	
19	HRA1101000A4	GASKET,FILTERHEAD	1	
20	EA00003787A	OILFILTER(84-120)	1	
21	HRA1100900B	BRACKET,OILFILTE	1	
22	EA00002852A	PRESSURE CONTORL VALVE	1	
23	24311-000160	O-RING, DYNAMIC (Φ16)	1	
24	24321-000600	SEAL,ORING	1	
25	EA00002818A	SPACER(PRESSURE C.V)	1	
26	EA00002900A	REINFORCEMENT BRACKET(COOLER SPACER)	1	
27	EA00000309A	OIL COOLER ASSY	1	
28	EA00000310A	BOLT COOLER, OIL	1	
29	26106-080202	SQR FLANGE BOLT	3	
30	HA09250000A3	SWITCH,OILPRESSURE	1	
31	23414-100000	PLAIN WASHER (D10)	5	
32	23887-100002	SCREW,HEXAGONHEADCAP	1	
34	HL03210000A		1	
35	HRA1101800A3	DIPSTICK	1	
36	26106-080162	SCREW,HEXFLANGEHEADCAP	1	
39	26106-060122	HEX BOLT (6-12)	2	
40	HRT0300500A4	PLUG,EXPANSION	1	
41	HRC1101900A3	NOZZLE,PISTON COOLING	4	
42	22351-030010	PIN, SPRING (3-01)	4	
43	23414-080000	WASHER, PLAIN (Φ8)	4	
44	HRC1102000A4	CHECK VALVE ASS'Y	4	
45	HRF1105000A4	ELBOW,PLAIN UNION	1	
46	23080-020000	CLAMP, V BAND	2	
47	HRU0430900		1	
48	EA00003504A	TUBE,TUR OIL DRAIN	1	
49	HP09350000A4	GASKET,OILDRAIN	1	
50	HA09220000A4	SCREW,BANJOCONNECTOR	2	
52	EA00003503A	TUBE,TUR OIL SUPPLY	1	
53	26106-080122	Bolt, Hexa (8-12)	1	
54	26106-060182	Bolt, Hexa (6-18)	2	

FIG 00205_12 A2300T8-ETX_4	COOLING SYSTEM	Year/Month 2020/02






FIG 00205_12 A2300T8-ETX_4	COOLING SYSTEM	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003252C	WATER PUMP ASS'Y	1	
14	24341-000280	O-RING, FIX (Φ28)	1	
18	HRA1200200A3	GASKET,WATERPUMP	1	
19	26106-080552	HEX FLANGE BOLT (D80)	3	
20	26106-080602	SCREW,HEXFLANGEHEADCAP	1	
21	EA00004415A	V-BELT(GREEN 2 A40.5")	1	
23	EA00003004A	V-PULLEY(FAN)	1	
23.2	HRU0140100A3	V-PULLEY	0	
28	EA00000543A	SPACER(FAN)	1	
28.2	EA00004571A	COOLING SYSTEM	0	
29	26106-080302	HEX BOLT, FLANGE	4	
32	HC09160000B4	COVER, THERMOSTAT	1	
34	HA10670000A4	GASKET,WATER PUMP -> HA10670000B4	1	
35	HK10030000A3	THERMOSTAT	1	
36	EA00002854A	COOLANT HOSE A, OIL COOLER	1	
37	EA00002855A	COOLANT HOSE B, OIL COOLER	1	
38	26106-080182	SCREW,HEXFLANGEHEADCAP	2	
40	HRC1204000A4	NIPPLE,PLAINPIPE	1	
41	HH12210000A3	SENSOR,GLOWPLUG	1	
42	23414-160000	WASHER,SEALING	1	
43	HH12190000A3	WATER TEMP SENSOR	1	
44	23414-100014	PACKING,COPPER	1	
45	FLW5100000A3	T-Joint	0	
60	23000-022000	CLAMP,HOSE	2	
61	23000-025000	CLAMP,HOSE	2	
62	CEE2080000A4	ELBOW,PLAINUNION	1	
63	FLW5110000A3	T-Joint	0	

FIG 00205_13 A2300T8-ETX_4	FUEL INJECTION PUMP	Year/Month 2020/02




FIG 00205_13 A2300T8-ETX_4	FUEL INJECTION PUMP	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00002882A	FUEL INJECTION PUMP	1	
2	HRA1300600A4	SUPPORT(AXLE LEVER)	1	
3	EA00002101A	LEVER, HOOK, ACCEL	1	
4	22272-000050	RING, CIRCLIP (Φ 05)	1	
5	HRA130020DA4	BRACKET(B),PUMP	1	
6	HRA130030DA4	BRACKET(A),PUMP	1	
7	26116-100162	SCREW,HEXAGONHEADCAP	2	
8	26106-080162	SCREW,HEXFLANGEHEADCAP	2	
9	26367-080002	HEX FLANGE NUT (Φ8)	1	
10	HRA0702100A4	KEY,PLAINWOODRUFF	1	

FIG 00205_14 A2300T8-ETX_4	FUEL INJECTION SYSTEM	Year/Month 2020/02




FIG 00205_14 A2300T8-ETX_4	FUEL INJECTION SYSTEM	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00000642A	INJECTOR	4	
10	HRA1502600B4	BRACKET,PIPE	1	
11	HRA1502700A4	RUBBER,BRACKET	2	
12	HRA1502800A4	CLAMP,TUBE	1	
13	HRA150050DB0	PIPE ASSY, FUEL SUPPLY A	1	
14	HRA150060DB0	PIPE ASSY, FUEL SUPPLY (B)	1	
15	HRA150070DB0	PIPE ASSY, FUEL SUUPLY C	1	
16	HRA150080DB0	PIPE ASSY, FUEL SUPPLY D	1	
17	HRA1500900C3	PIPE ASSY, FUEL RETURN	1	
18	HK13440000A4	GASKET,FUELMANIFOLD	4	
19	HK13450000A4	NUT,REGULARHEXAGON	4	
22	EA00000700A	TUBE, FUEL DRAIN	1	
23	23080-010000	CLAMP, V BAND	2	
24	HRA1502400C4	CONNECTOR, BANJO	1	
25	26367-060002	Nut, Hexa (Φ6)	2	

FIG 00205_15 A2300T8-ETX_4	FUEL SYSTEM	Year/Month 2020/02




FIG 00205_15 A2300T8-ETX_4	FUEL SYSTEM	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	HK13010000C2	FUEL FILTER ASSY	1	
2	EA00003140B	FILTER BRAKET ASSY	1	
3	26106-080162	SCREW,HEXFLANGEHEADCAP	2	
4	26106-080652	SCREW,HEXFLANGEHEADCAP	1	
5	EA00000173A	HOSE, FUEL ASSY	1	
6	23000-013000	Clip, Hose (Φ13)	2	

FIG 00205_16 A2300T8-ETX_4	STARTING MOTOR	Year/Month 2020/02




FIG 00205_16 A2300T8-ETX_4	STARTING MOTOR	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003037C	STARTER	1	
2	26216-120302	STUDBOLT	1	
3	22217-120000	WASHER, SPRING (Φ 12)	1	
4	26716-120002	BOLT,CYLINDER HEAD(B)	1	
5	EA00001429A	LAMP	1	

FIG 00205_17 A2300T8-ETX_4	GENERATOR & ELECTRIC DEVICE	Year/Month 2020/02




FIG 00205_17 A2300T8-ETX_4	GENERATOR & ELECTRIC DEVICE	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00004191A	ALTERNATOR ASS'T(12V-50A)	1	
1	EA00004190A	ALTERNATOR ASS'Y(12V-70A)	0	
35	HN21240000A4	SPACER,ALTERNATOR	0	
36	26116-100802	SCREW,HEXAGONHEADCAP	1	
36	26106-081052	SCREW,HEXFLANGEHEADCAP	0	
37	26716-100002	Nut, Hexa (Φ10)	1	
37	26716-080002	NUT,HEX (D8)	0	
38	HN41020000A3	BRACKET,ALTERNATOR	1	
39	RR15170000A4	WASHER 8.5X20X3.2	1	
41	22217-100000	WASHER, SPRING (Φ 10)	1	
42	22127-100000	WASHER, PLAIN (Φ 10)	2	
42	22127-080000	WASHER, PLAIN (D80)	0	
43	HK15170000A4	PLUG, PREHEAT	4	
44	HRA1801300A4	CONNECTOR,ELECTRICAL	1	
49	26013-080302	HEX BOLT W/WASHER	1	
50	HA00000920A	HARNESS H	1	
51	HA00000861C	HARNESS A	1	

FIG 00205_18 A2300T8-ETX_4	DPF MOUNTING	Year/Month 2020/02




FIG 00205_18 A2300T8-ETX_4	DPF MOUNTING	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003507A	DPF SUPPORT(A)	1	
2	EA00003508A	DPF SUPPORT(B)	1	
3	EA00003509A	DPF SUPPORT(C)	1	
4	EA00003530A	DPF SUPPORT(D)	1	
5	26106-080222	SCREW, HEX FLANGE HEAD CAP	8	

FIG 00205_19 A2300T8-ETX_4	DPF OPTION	Year/Month 2020/02




FIG 00205_19 A2300T8-ETX_4	DPF OPTION	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003312A	EXHAUST GAS TEMP. SENSOR	1	
2	EA00003291A	DIFFERENTIAL PRESSURE SENSOR	1	
3	EA00003287A	DIFFERENTIAL PRESSURE SENSOR HOSE A	1	
4	EA00003288A	DIFFERENTIAL PRESSURE SENSOR HOSE B	1	
5	26106-080162	SCREW,HEXFLANGEHEADCAP	6	
6	26367-080002	HEX FLANGE NUT (Φ8)	2	
7	26216-080202	STUDBOLT	2	
8	EA00003227C	DPF ASSY(6.77)	1	

FIG 00205_20 A2300T8-ETX_4	DATAPLATE	Year/Month 2020/02




FIG 00205_20 A2300T8-ETX_4	DATAPLATE	Year/Month 2020/02

KeyNo.	Part Number	Part Name	Quantity	Other
1	EA00003772A	DATA PLATE(LUXEN55)	1	
2	22685-320601	RIVET	4	