

Scheduled Maintenance



Model: Current Km/mi:						
Plate Number: Date of Registration:	/		/			
Customer Name: Current Date:	/		/			
* Constitution intervention of the Microsoft Education of the Microsoft Edu	. x 1.000 1	12 7.5	24 15	36 22.5	48 30	Time (months)
Reading of the error memory with DDS and check of Software version update on control units	•	•	•	•	•	12
☐ Check the presence of any technical updates and recall campaigns	•	•	•	•	•	12
☐ Change engine oil and filter	•	•	•	•	•	12
☐ Clean engine oil intake filter				•		36
Check engine oil pressure			•		•	24
Check and/or adjust valve clearance		•	•	•	•	
Check timing belt tension		•		•		
Change timing belts			•		•	24
Check and clean spark plugs. Change, if necessary			•		•	24
Check and clean air filter		•		•		
Changing air filter			•		•	24
Check brake and clutch fluid level	•	•	•	•	•	12
Change brake and clutch fluid				•		36
Check and adjust brake and clutch controls		•	•	•	•	12
Check and lubricate throttle/cold start control		•	•	•	•	12
Check pad wear and brake discs. Change, if necessary	•	•	•	•	•	12
Check steering head bearings and wheel hubs			•		•	24
Check rear wheel flexible coupling			•		•	24
Check clutch plates pack. Change, if necessary		•	•	•	•	
Check tightening of the safety components (brake disc flange screws, brake calliper screws, front/rear wheel nuts, front and rear sprocket nuts, engine/frame screws)	•	•	•	•	•	12
Check and lubricate the rear wheel shaft			•		•	
Check the drive chain tension and lubrication	•	•	•	•	•	12
Check final drive wear (chain, front and rear sprockets) and chain sliding shoes	•	•	•	•	•	12
☐ Visual check of front fork and rear shock absorber seals	•	•	•	•	•	12
Change front fork fluid				•		36
Check the freedom of movement of the side and central stand (if installed)	•	•	•	•	•	12
Check rubbing points, clearance and freedom of movement of hoses and electric wiring in view	•	•	•	•	٠	12
Check coolant level (only for four valve engine)	•	•	•	•	•	12
Change coolant (only for four valve engine)		_		•		36
Check electric fan operation (only for four valve engine)	•	•	•	•	•	12
Check external fuel lines	•	•	•	•	٠	12
Lubrificate and grease	•	•	•	•	•	12
Check tyre pressure and wear	•	·	•	<u>.</u>	•	12
Check the battery charge level	•	•	•	•	•	12
Check throttle body sinchronisation and idling		•	•	<u>.</u>	٠	
Check the operation of the safety electrical devices (side stand sensor, front and rear brake switches, engine stop switch, gear/neutral sensor)	•	•	•	•	•	12
Check the indicators and lighting	•	•	٠	<u>.</u>	٠	12
Reset Service indication through DDS		•	•	•	•	
Road test of the motorcycle, testing the safety devices (ex. ABS and DTC)	•	•	٠	•	٠	12
Softly clean of the motorcycle	•	•	•	•	•	12
Fill out that the service was performed in on-board documentation (Service Booklet)	•	•	•	•	•	12

* Tick the box next to the interventions carried out during Scheduled Maintenance