BMW Motorrad

Maintenance schedule 0611 - K 1600 GT, K48



| | Odometer reading | |
|---|--|--|
| Customer Registration No. | | |
| | | |
| Date | | |
| Order No. | Mechanic's + Manager's signature | |
| 00 00 111 BMW Service | | |
| Performing vehicle test with BMW Motorrad diagnostic system | | |
| 11 00 609 Oil change in engine with filter (for maintenance) Annually or every 10,000 km | | |
| 11 34 502 Checking valve clearance (for main | tenance) Every 30,000 km | |
| 12 12 509 Replace all spark plugs (as part of maintenance) Every 30,000 km | | |
| 13 72 505 Replace air filter cartridge (for main | tenance) Every 20,000 km | |
| 33 74 500 Oil change in rear bevel gears Every two years or every 20,000 | | |
| Draining oil condensate hose | | |
| Visually inspecting brake pipes, brake hoses and connections | | |
| Checking front brake pads and brake discs for wear | | |
| 34 00 548 Changing brake fluid, front brakes | Initially after one year, then every two years | |
| Checking rear brake pads and brake disc for wear | | |
| 34 00 549 Changing brake fluid, rear brakes | Initially after one year, then every two years | |
| Checking clutch system | | |
| Checking coolant level | | |
| Checking tire pressures and tread depth | | |
| Checking ease of movement of side stand | | |
| Checking ease of movement of center stand | | |
| Checking lights and signaling equipment | | |
| Function test, engine start suppression | | |
| Final inspection and check of roadworthiness | | |
| Performing vehicle test with BMW Motorrad diagnostic system | | |
| Setting service-due date and service countdown distance | | |
| Checking battery charge state | | |

| Confirming BMW Service in on-board documentation | |
|--|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |