BMW Motorrad

Maintenance schedule





Customer	Registration No.	Odometer reading	Equipment trim-level variant: 0636 - Centre stand 0645 - (BMW Motorrad Integral ABS 0630 - (BMW Motorrad Integral ABS	
Order No.	Date	Mechanic's + Manager's signature		
Reading fault men	nory with (BMW Motorrad) dia	gnostic system		
Engine-oil change	, with filter			
23 00 510 Gearbo	x-oil change (maintenance) *)	ever	ry two years or every 40,000 km	
Adjusting valve cle	earance			
12 12 509 Replace	e all spark plugs (as part of ma	aintenance) *)	every 40,000 km	
Replacing air filter	element			
16 12 525 Replace	e the fuel filter (during mainten	nance) *)	every 40,000 km	
12 31 657 Replea	ce belt for generator (as part c	of maintenance) *)	every 60,000 km	
Visual inspection of	of hydraulic clutch system			
34 00 616 Changii (as part of mainter	ng brake fluid in Integral ABS nance) *)	wheel circuit, front	every two years	
34 00 617 Changii (as part of mainter	ng brake fluid in Integral ABS nance) *)	wheel circuit, rear	every two years	
34 00 608 Change (maintenance) *)	brake fluid in entire ABS con	trol circuit	every four years	
Checking freedom	of movement of the throttle ca	able and checking for kinks and cha	fing	
Checking tyre pres	ssures and tread depth			
Checking ease of	movement of side stand			
Checking ease of	movement of centre stand			
Checking lights an	d signalling equipment			
Function test, eng	ine start suppression			
34 00 650 Brake c	heck for BMW Motorrad Integ	ral ABS (as part of maintenance) *)		
Checking synchro	nisation			
Test ride as final in	nspection and function check			



Reading fault memory with (BMW Motorrad) diagnostic system				
Checking battery charge state				
Confirming BMW Service in on-board documentation				
*) Billed as a separate item	not as per the normal schedule			
BMW Motorrad, UX-VA-4 06.06.06		BMW recommends	Castrol	